

USER MANUAL

cFlamer Waver

V1.0
2026/04/14

SHOWVEN®



SHOWVEN Technologies Co., Ltd

Thanks for choosing SHOWVEN cFlamer Waver, we wish it will bring you lots of exciting moments.

Please read the following user's manual and related product installation guide carefully before operating this device.

▲ Safety Instructions

1. Safety icons explanation

Safety instructions warn of hazards when handling equipment and provide information on how to avoid those hazards. They are classified according to the severity of the hazard and are divided into the following groups. Please do follow all safety instructions in this document!

DANGER: Indicates a hazardous situation that, if not avoided, will result in death or serious injury. (This signal word is limited to the most extreme situations)

WARNING: Indicates a hazardous situation that, if not avoided, could result in serious injury.

CAUTION: Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

NOTICE: Provide additional or supplementary information.

2. General Safety Instructions

- ∨ Unauthorized repair are prohibited, it may cause serious incident.
- ∨ Make sure power supply is consistent with the rated voltage of the equipment, and the socket must be well grounded. Unplug and turn off the machine when not use.
- ∨ Please connect DMX cable before power on cFlamer Waver, and ensure that the communication command is disabled, and the safety switch of device is under test mode.
- ∨ After turning on the device, no person allows to stay in the danger area. Ensure all persons that are part of the show be informed about the safety distance, risks and functions of the device.
- ∨ Always have a CO₂ fire extinguisher and an extinguishing blanket in case of needed.
- ∨ If there be any doubt as to the safety operation of the device in any circumstances, the device should be taken out of service immediately. Be sure the device is in good operating condition before use. If fail to fire correctly, immediately shut down and check it accordingly. Any questions please always contact SHOWVEN (info@showven.cn) for help.
- ∨ Be sure to use high quality fuels, otherwise, it is easily leads to failure or danger. Please keep fuels away from heat source, sparks, fire or other possibility of ignition. Do not smoke!
- ∨ The operator responsible for the control of flame system must always have a clear view of the device, so that he/she can stop the show immediately when there is danger. The main AC power switch should be near operator. So that operator can turn off the power of all devices in case of abnormal.
- ∨ The device shall not be altered and applied to other use purpose.

3. Disclaimers:

SHOWVEN technologies Co., Ltd excludes liability for unsafe situations, accidents and damages resulting from:

1. Ignoring warnings or regulations as shown on product manual or this manual.
2. Use for other applications or circumstances other than those indicated herein.
3. Changes to the device, including use of non-original spare parts, lack of maintenance etc.
4. Dismantling device without authorization from SHOWVEN.
5. Use this machine by unqualified or untrained personnel.
6. Improper use of machine.


WARNING

A dry powder fire extinguisher, a carbon dioxide fire extinguisher and a fire blanket must be equipped next to the equipment. Someone must be on duty during operation. In case of fire accident, dry powder fire extinguisher can be used when the fire is large, and a carbon dioxide fire extinguisher can be used when the fire is small.

▲ **Technical Specifications**


- ∨ **Housing Material:** Aluminum + Stainless steel
- ∨ **Dimension:** 615×330×305mm
- ∨ **Weight:** 37.5kg
- ∨ **Input:** AC100-120V / AC200-240V, 50/60Hz
- ∨ **Work Power:** 500W
- ∨ **Ignition:** Dual, high voltage electron ignition
- ∨ **Dual Valve:** Yes
- ∨ **Control:** DMX , 9-60V pyro signal, Wireless with Wireless DMX Receiver (5-PIN DMX IN with DC5V power supply)
- ∨ **DMX:** 3-pin and 5-pin DMX IN / OUT
- ∨ **E-Stop Interface:** Yes, can be connected in series
- ∨ **Effect Direction:** 210° (±105°)
- ∨ **Flame Height:** Nozzle cH: 8-10m / Nozzle cL: 5-6m (No wind, color fluid)
- ∨ **Tank Capacity:** 10L
- ∨ **Fuel:** Color Fluid (prepared with SHOWVEN color additives), ISOPAR L, ISOPROPANOL
- ∨ **Color Additives Available:** FX-RED, FX-GREEN, FX-BLUE, FX-YELLOW, FX-PURPLE
- ∨ **Fuel Tube Filter:** Yes
- ∨ **Tip sensor:** Yes
- ∨ **Usage in Rain:** Yes
- ∨ **ARM light:** Yes

▲ Structure




1. Rear panel
2. Fuel tank cover
3. Top panel
4. Fire box
5. Handle
6. Nozzle
7. Igniter (Dual)
8. Fire box module

Diagram of bottom panel



▲ Rear Panel




1. LCD display panel
2. Touch button
3. Power Switch (with Power indicator light)
4. Power IN / OUT
5. Safety switch
6. 3-pin XLR IN/OUT
7. 5-pin XLR IN/OUT (5-PIN XLR IN can charge for wireless DMX pen through pin1 and 4, pin4 with DC5V power supply)
8. 9-60V pyro signal port
9. E-stop interface
10. ARM indicator light

▲ Display and setting

1. Welcome interface

Software Version	F18-260105
Serial Number	*****
Pump Run Time	00:00:00
Ignition Times	xx

2. Main interface



- 1.) Status Bar
 - : appears when "External Trigger" is "ON"
 - : appears when "safety switch" stay at "USER MODE"
- 2.) Data Bar
 - DMX:** DMX address, Background turns from BLACK to RED when DMX cable was connected.

SAFE: Safety address, Background turns from BLACK to RED when DMX cable was connected and safety channel activated.

PRES: Pressure value. Background turns from BLACK to RED when pressure reached / exceed 90% of "set pressure" value.

- 3.) Message Bar
USER MODE / error or alert information display, Background color turns to RED when under "USER MODE".
- 4.) Touch Button function display:
First Button: MENU / BACK
Second Button: UP / LEFT
Third Button: DOWN / RIGHT
Fourth Button: MONI / EDIT / SAVE

3. ARM indicator light



Operators can enable/disable the arm indicator light by set the "ARM STATE" in ADVANCED menu. If "ARM STATE" is ON, there will be three status:

OFF: DMX signal input

BLINK: DMX armed or Ext Ignite in advanced menu is ON

ON: no DMX signal and Ext Ignite in advanced menu is OFF

4. Alert Message

Alert Message	Why it appears	How to remove
E0 Test Mode	Safety Key locate at TEST MODE	Switch Key to USER MODE
E0 Factory Mode	Factory mode	Switch to Normal mode
E0 ExtIgnite ON	"External Trigger" set to sequence No.1 - No.95	Set "External Trigger" to "OFF" in Advanced menu
E0 Ignition Disenable	Any of "Ignition" 1-2 is "Disenable"	Set "Ignition" 1-2 to "Enable" in Factory menu
E0 Invert	"Invert" is set to ON in advanced menu	Set to OFF
E0 Pump Disable	"Pump" is set to "Disable" in advanced menu	Set "Pump" to Enabled
E0 Key Lock	"Key Lock" set to "ON" in advanced menu, touch button no operation in 30s	Restart machine

5. Error Message

Error Message	Why it appears	How to remove
E1 Pressure Err	Consecutive pressurize failure times exceed "Pressure Fail Cnt" setting value in factory menu. Possible reasons: 1. Fuel tank empty 2. Pump failure 3. Fuel leakage 4. Pressure sensor damage 5. Pressure relief valve malfunction	Restart machine and check below items accordingly 1. Fill tank 2. Check pump 3. Check whether there is leakage inside machine 4. Check pressure sensor 5. Check relief valve
E2 P Relief Err	Pressure high after depressurize. Possible reasons: 1. Pressure relief valve malfunction 2. Fuel pipe block	Restart machine and check below items accordingly 1. Pressure relief valve 2. Check fuel pipe
E3 Press Sensor	Pressure sensor disconnect / damage	please check pressure sensor.
E4 Motor Err	Flame head not reached target position in setting time	Restart and check flame head
E6 Tip Err	1. Machine slant over 45°, it stops running. 2. Main board malfunction	1. Tip setting set to OFF, or horizontal install machine. 2. Replace main board

6. Monitoring Interface

Press "MONI" enter below interface

Menu	Explanation
Pressure	Current pressure value. -62 means pressure sensor disconnected
DC voltage	DC power supply voltage
Pump	Pump current value
Range of angle limit	The range of current angle limit (Mini. NO ~ Max. NO)
User Mode	<15V is under test mode
Pump Run Time	Accumulative pump working time
Ignition Times	Accumulative ignition times
Angle Data	Flame head deviation between actual angle and signal angle

7. Menu Interface

Press "MENU" enter below interface

Menu	Explanation
MAIN	Main menu
ADVANCED	Advanced menu
TEST	Test menu
FACTORY	Factory menu (factory use only)

8. Menu Interface

Press "MENU" enter below interface

Menu	Explanation
MAIN	Main menu
ADVANCED	Advanced menu
TEST	Test menu
FACTORY	Factory menu (factory use only)

9. Main menu

Select "MAIN" in menu interface, press "EDIT" enter main menu. Use UP / DOWN / SAVE to change the parameters.

Menu	Range	Default	Explanation
Set DMX Address	1~507	1	DMX address setup
Min Angle Limit	1-15	1	Restrict the minimum nozzle output direction
Max Angle Limit	1-15	15	Restrict the maximum nozzle output direction
RDM XXXXXXXXX	ON/OFF	OFF	RDM function ON/OFF

10. Advanced menu

Select "ADVANCED" in menu interface, press "EDIT" enter advanced menu. Use UP / DOWN / SAVE to change the parameters.

Items	Contents	Default	Description
External Trigger	OFF / ON	OFF	Trigger through 9-60V pyro ignition signal
Set Ext Sequence	1-95	95	Preset sequence triggered by pyro signal
Head to middle	OFF / ON	ON	ON: Channel 1=0, Firing head will back to middle position (NO.8) after running a preset sequence.

			OFF: Firing head position after firing will be decided by CH1 DMX value.
Invert	OFF / ON	OFF	When turned on, all angles will be mirrored.
Motor Disabled	ON/OFF	OFF	ON: output nozzle motor disabled
Automatic Limit	ON/OFF	OFF	ON: output nozzle will check the angle block limit automatically after power on machine
Motor Err Switch	ON/OFF	OFF	ON: report error when nozzle not arrived designed position on time
Tip Setting	OFF / ON	ON	Turn ON/OFF tip over function
Key Sound	ON/OFF	ON	Touch button sound ON / OFF
ARM State	ON/OFF	ON	ARM indicator light ON/OFF setting
LCD Backlight	ON/OFF	OFF	LCD backlight ON/OFF. When ON, screen will flash when firing; OFF: LCD screen will turn off when no operation.
Key Lock	ON/OFF	OFF	ON: Touch button will disable if there is no operation in 30s. restart machine to active touch button.
Default Parameter	ON/OFF	OFF	Reset default parameter settings

11. Test menu

Please disconnect DMX connection before enter test menu.


Select "TEST" in menu interface, press "EDIT" enter test menu. Use UP / DOWN / SAVE to change the parameters.

"External Trigger" will disable after enter TEST menu, Pressure relief valve will open, below related items will shows Running when testing, shows Finish after test finished.

Items	Description
ARM Test	Test ARM indicator light, blink once/s, blink 3 times
Jet1 Valve Test	Switch safety switch to USER MODE, Jet valve 1 ON/OFF 3 times, 1s per time
Jet2 Valve Test	Switch safety switch to USER MODE, Jet valve 2 ON/OFF 3 times, 1s per time
Relief Test	Relief valve ON/OFF 3 times, 1s per time
Igniter 1 Test	Igniter 1 ON/OFF 3 times, 1s per time
Igniter 2 Test	Igniter 2 ON/OFF 3 times, 1s per time
Pump Test	Pump will pressurize to "Set Pressure" value and keep 2s, and display "F". If pressurize time exceed setting value of "Max Pressure Limit", means pump test fail, it will display "E". Display "R" means machine is pressurizing.
Drain (CAUTION)	<ol style="list-style-type: none"> 1. Switch safety key to USER MODE 2. Select "Drain", press "EDIT", there will be 5s delay before corresponding pump activated, please away from the machine. 3. Pump pressurize 7s, If the pressure reaches the set pressure within 7s, then pump will stop working. Otherwise, pump will enter the emptying process. Open the corresponding JET valve for 0.3 seconds and stop for 1.7 seconds to empty the air from the pipe. Repeat three times. Please be aware that there will be some fuel drop to the ground. <p>Please keep the safety isolation zone clear before execute Drain test!</p>
Motor Test	Output nozzle motor test: angle 1-15 wave sequence
Motor Run Test 1	Output nozzle motor test 1: angle 1, 8 step sequence
Motor Run Test 2	Output nozzle motor test 2: angle 8, 15 step sequence
Motor Run Test 3	Output nozzle motor test 3: angle 1, 8 wave sequence
Motor Run Test 4	Output nozzle motor test 4: angle 8, 15 wave sequence

▲ Firing Angles:

The firing angle for CFLAMER WAVER is $\pm 105^\circ$, from the Audience Side view, there are altogether 15 firing angles as below.



▲ cFlamer Waver Firing Sequences

cFlamer Waver has 95 preset sequences, operator use related channel DMX value or sequence No. to access certain sequence. Below, you can find sequence list and single ignitions.

Single Ignition Sequence List

No.	Ignition angle	Description	Nozzle movement	Sequence Duration (For reference)	CH5 DMX Value
1	-105°	Single Ignition SHORT flame	Static	0.19s	3-5
2	-90°	Single Ignition SHORT flame	Static	0.19s	6-7
3	-75°	Single Ignition SHORT flame	Static	0.19s	8-10
4	-60°	Single Ignition SHORT flame	Static	0.19s	11-12
5	-45°	Single Ignition SHORT flame	Static	0.19s	13-15
6	-30°	Single Ignition SHORT flame	Static	0.19s	16-17
7	-15°	Single Ignition SHORT flame	Static	0.19s	18-20
8	0°	Single Ignition SHORT flame	Static	0.19s	21-22
9	15°	Single Ignition SHORT flame	Static	0.19s	23-25
10	30°	Single Ignition SHORT flame	Static	0.19s	26-28
11	45°	Single Ignition SHORT flame	Static	0.19s	29-30
12	60°	Single Ignition SHORT flame	Static	0.19s	31-33
13	75°	Single Ignition SHORT flame	Static	0.19s	34-35
14	90°	Single Ignition SHORT flame	Static	0.19s	36-38
15	105°	Single Ignition SHORT flame	Static	0.19s	39-40
16	-105°	Single Ignition LONG flame	Static	0.56s	41-43
17	-90°	Single Ignition LONG flame	Static	0.56s	44-45
18	-75°	Single Ignition LONG flame	Static	0.56s	46-48
19	-60°	Single Ignition LONG flame	Static	0.56s	49-50
20	-45°	Single Ignition LONG flame	Static	0.56s	51-53
21	-30°	Single Ignition LONG flame	Static	0.56s	54-56
22	-15°	Single Ignition LONG flame	Static	0.56s	57-58
23	0°	Single Ignition LONG flame	Static	0.56s	59-61
24	15°	Single Ignition LONG flame	Static	0.56s	62-63
25	30°	Single Ignition LONG flame	Static	0.56s	64-66

26	45°	Single Ignition LONG flame	Static	0.56s	67-68
27	60°	Single Ignition LONG flame	Static	0.56s	69-71
28	75°	Single Ignition LONG flame	Static	0.56s	72-73
29	90°	Single Ignition LONG flame	Static	0.56s	74-76
30	105°	Single Ignition LONG flame	Static	0.56s	77-79

Step Sequences List

No.	Ignition angle NO.	Description	Nozzle movement	Sequence Duration	CH5 DMX Value
31	Step from 1-15	SHORT flame Step sequence	L -> R	2.66s	80-81
32	Step from 15-1	SHORT flame Step sequence	R -> L	2.66s	82-84
33	Step 5>8>11	SHORT flame Step sequence	L -> R	0.92s	85-86
34	Step 11>8>5	SHORT flame Step sequence	R -> L	0.92s	87-89
35	Step 6>10	SHORT flame Step sequence	L -> R	0.75s	90-91
36	Step 10>6	SHORT flame Step sequence	R -> L	0.75s	92-94
37	Step 4>6>8>10>12	SHORT flame Step sequence	L -> R	1.27s	95-96
38	Step 12>10>8>6>4	SHORT flame Step sequence	R -> L	1.27s	97-99
39	Step 8>6>10>4>12	SHORT flame Step sequence	M>L>R>L>R	1.60s	100-101
40	Step 8>10>6>12>4	SHORT flame Step sequence	M>R>L>R>L	1.60s	102-104
41	Step from 1-15	LONG flame Step sequence	L -> R	7.78s	105-107
42	Step from 15-1	LONG flame Step sequence	R -> L	7.78s	108-109
43	Step 5>8>11	LONG flame Step sequence	L -> R	1.82s	110-112
44	Step 11>8>5	LONG flame Step sequence	R -> L	1.82s	113-114
45	Step 6>10	LONG flame Step sequence	L -> R	1.25s	115-117
46	Step 10>6	LONG flame Step sequence	R -> L	1.25s	118-119
47	Step 4>6>8>10>12	LONG flame Step sequence	L -> R	2.68s	120-122
48	Step 12>10>8>6>4	LONG flame Step sequence	R -> L	2.68s	123-124
49	Step 8>6>10>4>12	LONG flame Step sequence	M>L>R>L>R	2.88s	125-127
50	Step 8>10>6>12>4	LONG flame Step sequence	M>R>L>R>L	2.88s	128-130

Wave Sequence List

No.	Ignition angle NO.	Description	Nozzle movement	Sequence Duration	CH5 DMX Value
51	Wave 5 -->11	Middle wave sequence	L -> R	1.87s	131-132
52	Wave 11-->5	Middle wave sequence	R -> L	1.87s	133-135
53	Big wave 1--15	LONG wave sequence	L -> R	4.08s	136-137
54	Big wave 15--1	LONG wave sequence	R -> L	4.08s	138-140
55	Wave 8-->1	Middle wave sequence	M -> L	2.09s	141-142
56	Wave 8-->15	Middle wave sequence	M -> R	2.09s	143-145
57	Wave 1-->8	Middle wave sequence	L -> M	2.31s	146-147
58	Wave 15-->8	Middle wave sequence	R -> M	2.31s	148-150
59	Wave 8-->11	SHORT wave sequence	M -> R	0.99s	151-152
60	Wave 8-->5	SHORT wave sequence	M -> L	0.99s	153-155
61	Wave 5-->8	SHORT wave sequence	L -> M	1.08s	156-158
62	Wave 11-->8	SHORT wave sequence	R -> M	1.08s	159-160

Additional Sequences List

No.	Ignition angle NO.	Description	Nozzle movement	Sequence Duration	CH5 DMX Value
63	Step 3>13	SHORT flame Step sequence	L -> R	0.93s	161-163
64	Step 13>3	SHORT flame Step sequence	R -> L	0.93s	164-165
65	Step 3>13	LONG flame Step sequence	L -> R	1.63s	166-168
66	Step 13>3	LONG flame Step sequence	R -> L	1.63s	169-170
67	Step 8-13	SHORT flame Step sequence	M -> R	1.55s	171-173
68	Step 13-8	SHORT flame Step sequence	R -> M	1.55s	174-175
69	Step 8-13	LONG flame Step sequence	M -> R	3.24s	176-178
70	Step 13-8	LONG flame Step sequence	R -> M	3.24s	179-181

71	Step 8-3	SHORT flame Step sequence	M -> L	1.54s	182-183
72	Step 3-8	SHORT flame Step sequence	L -> M	1.54s	184-186
73	Step 8-3	LONG flame Step sequence	M -> L	3.24s	187-188
74	Step 3-8	LONG flame Step sequence	L -> M	3.24s	189-191
75	Step 3-13	SHORT flame Step sequence	L -> R	1.98s	192-193
76	Step 13-3	SHORT flame Step sequence	R -> L	1.98s	194-196
77	Step 2-14	SHORT flame Step sequence	L -> R	2.32s	197-198
78	Step 14-2	SHORT flame Step sequence	R -> L	2.32s	199-201
79	Step 8>5>11	SHORT flame Step sequence	M>L>R	0.93s	202-203
80	Step 8>11>5	SHORT flame Step sequence	M>R>L	0.93s	204-206
81	Step 5-11	SHORT flame Step sequence	L -> R	1.28s	207-209
82	Step 11-5	SHORT flame Step sequence	R -> L	1.28s	210-211
83	Wave 8-->13	Middle wave sequence	M -> R	1.70s	212-214
84	Wave 13-->8	Middle wave sequence	R -> M	1.70s	215-216
85	Wave 8-->3	Middle wave sequence	M -> L	1.60s	217-219
86	Wave 3-->8	Middle wave sequence	L -> M	1.60s	220-221
87	Wave 3-->13	LONG wave sequence	L -> R	3.06s	222-224
88	Wave 13-->3	LONG wave sequence	R -> L	3.06s	225-226
89	Step 6-10	SHORT flame Step sequence	L -> R	1.32s	227-229
90	Step 10-6	SHORT flame Step sequence	R -> L	1.32s	230-232
91	Step 6-10	LONG flame Step sequence	L -> R	2.73s	233-234
92	Step 10-6	LONG flame Step sequence	R -> L	2.73s	235-237
93	Wave 6 -->10	LONG wave sequence	L -> R	1.52s	238-239
94	Wave 10-->6	LONG wave sequence	R -> L	1.52s	240-242
>94	8(0°)	Single Ignition LONG flame	Static	max. 8s	243-255

▲ DMX CONTROL

cFlamer Waver occupies 6 functional channel.

Channel	Function	Value
CH1	Manual Angle setup	0~255: angle change from -105° to 105° 128: straight upward (0°)
CH2	Manual Nozzle Waving Speed setup	0 and 255: Max Speed 1~254: Speed increase
CH3	Firing ON/OFF	0~253: Firing OFF 254~255: Firing ON
CH4	Firing Duration setup	0 and 255: permanent fire (10s is limit duration time) 1~254: 10~2540ms duration time (Manual firing duration = DMX Value * 10ms)
CH5	Preset sequence setup	0-2: no preset sequence 3-255: preset sequence DMX value = 2 + Sequence No.*2.55 (ROUND OFF)
CH6	Firing Enable / Disable	0~49 and 201~255: Firing Disable (Emergency STOP) 50~200: Firing Enable

Channel 1 (CH1): Manual Angle Setup

Angle No.	Angle	DMX Value
1	-105°	0
2	-90°	18
3	-75°	36
4	-60°	54
5	-45°	73
6	-30°	91
7	-15°	109
8	0°	128
9	15°	146
10	30°	165

11	45°	183
12	60°	201
13	75°	219
14	90°	237
15	105°	255

1. The first channel controls the firing angle. It defines to which angle the nozzle of cFlamer Waver move to. The angle can be chosen anywhere between -105° to +105° (DMX value 0 to 255)

2. The DMX value for angle of 0° is 127.5 (round up 128). Use this value, following formula can be used to calculate all other angles ∠ in degree. Please always note the prefix of the angle

$$\text{DMX Value} = 127.5 + (\angle * 1.2145)$$

Channel 2 (CH2): Manual Nozzle Waving Speed Setup

CH2: Nozzle Waving Speed Setup			
DMX Value	0	1-254	255
Speed	Max Speed	Incremental of Speed	Max Speed

The second channel defines the nozzle waving speed. It work together with Channel 1 for manual firing

Channel 3 (CH3): Firing ON/OFF

CH3: Ignition		
DMX Value	0-253	254-255
Firing	Firing OFF (igniter diable)	Firing ON (igniter enable)

The third channel activates the actual firing. If the DMX value of this channel higher than 253, the CIRCLE FLAMER will firing.

Channel 4 (CH4): Firing Duration setup

CH4: Manual Firing Duration setup								
DMX Value	0	1	2	3	4	254	255
Firing Duration	Permanent	10ms	20ms	30ms	40ms	2540ms	Permanent

The fourth channel is the firing duration setup

Below formula can be used to calculate the firing duration (ms):

$$\text{DMX Value} = t/10$$

Channel 5 (CH5): Program Sequence setup

The fifth Channel allows to firing a preset sequence. Three DMX values can be used for one of the programmed firing sequence from above sequence list (refer to above sequence list table).

Below formula can be used to calculate firing sequence:

$$\text{DMX Value} = 2 + \text{Sequence No.} * 2.55$$

CH5: Sequence List							
DMX Value	0~2	3~5	6~7	8~10	11~12	225-226
Sequence No.	N/A	1	2	3	4		88

Channel 6 (CH6): Firing Enable / Disable

The sixth channel is the working mode of pump.

When the safety lock located at TEST MODE, set DMX value between 50-200 to test the system. For safety, the device will not pressurize.

When the safety lock located at USER MODE, the device pressurize activated by set DMX value between 50-200.

CH6: Mode setup			
DMX Value	0-49	50-200	201-255
Mode	Firing disable	Firing enable	Firing disable

▲ Operation

1. Safety distance explanation

Safety distance for cFlamer Waver divided into two parts safety radius around machine (a) and safety distance at firing direction (b). No person and flammable materials are allowed to stay inside the safety isolation zone when flamer was armed.


The safety radius around machine depends on the firing height (nozzle size).

For safety distance at firing direction equals to maximum firing height * 1.5. cFlamer Waver with maximum $\pm 105^\circ$ waving firing angles, when firing step sequence, wave sequence or additional sequences the safety isolation zone is a three-dimensional sector area.

Nozzle Type	Max. Flame Height	Safety Radius (a)	Safety Distance at Firing Direction (b)
SFSMA033 Nozzle cL	6m	2m	9m
SFSMA037 Nozzle cH	10m	3m	15m

The cFlamer Waver safety isolation zone is a three-dimensional space with a cross-section of 210° sector enclosed by a and b (check below diagram). We can understand it as a safety area formed by a safety column with diameter of a, height of b rotate of ± 105 degrees. Unauthorized persons and objects are strictly prohibited from entering. Depending on the firing sequence / angles the sector area changes accordingly.

For angled installation, the safety distance both around machine and firing direction should shift accordingly.



Safety distance in windy environment

The safety isolation zone radius (a) increase with wind direction and wind speed (v, m/s). The safety distance in windy conditions can be calculated as below:

For Nozzle cH: $a = 3 + v$;

For example when the wind speed is 3m/s, we use the Nozzle cH, then the safety isolation zone radius should be 6m.


CAUTION:

When the wind speed ≥ 8 m/s (wind force ≥ 5), please use it with caution. When wind speed ≥ 17 m/s (wind force ≥ 8) , please stop use flamer.

2. Install cFlamer Waver

- Choose the correct nozzle, ensure the installation position of cFlamer Waver meet above safe distance requirements. New cFlamer Waver supplied with a nozzle cH which generate up to 10m flame.
- Horizontal installation is preferred for cFlamer Waver. If need to install cFlamer Waver in angles, to avoid fake error message please turn the TIP Setting to OFF status first. cFlamer Waver with

maximum tilt angle of 45° or -45°, and it can be angled to two directions as show in below picture. Besides please be aware the fuel level in fuel tank to avoid fuel leakage when tilt installation.



- c) For truss installations always connect with safety rope to ensure extra safety. If there is any other national or regional guidelines please follow it accordingly.
- d) Double confirm the machine was firmly installed.

3. Color fluid preparation

- a) Ensure all containers, fuel tanks etc are clean and free of impurities. Highly recommended to use container/fuel tank with a fixed color, not mix with different colors. If you have no extra tanks, please wash container / fuel tank with clean water thoroughly before use another color fluid.
- b) When wash the fuel tank, add half of the fuel tank capacity of clean water, shake it repeatedly for 30 seconds, pour out the water, and repeat the cleaning process twice.
- c) Perform the mixing operation according to the instructions on the color additive label. For blue, pay special attention to the proportion and addition order. Add 2 bottles (125ml*2) of BLUE A liquid to 5L diluent liquid and shake well, and then add 15ml BLUE B liquid. For other colors, just add 125ml color additive to 5L diluent liquid and shake well.
- d) There will be solid precipitate at the bottom of color additive bottle when environment temperature is low, please shake repeatedly to dissolve the solid precipitate before add it to the methanol.
- e) Please shake and mix the color fluid well before use.
- f) The prepared color fluid needs to be stored with a cap and implemented in accordance with the requirements of the diluent liquid MSDS or local regulations.

NOTICE:

Ensure that the purity of diluent liquid.

NOTICE:

The optimal viewing condition for the color flame effect is in a dark environment.

WARNING:

The preparation operation should be carried out in a well-ventilated place, away from fire, sparks and heat sources. Dry powder or carbon dioxide fire extinguishers should be prepared for use in the operation site.

WARNING:

cFlamer series product compatible with color fluid only prepared with SHOWVEN original color additives, other colored fuels are forbidden to use on the product, It will sure damage the machine.

4. Fuel the cFlamer Waver

- a) Switch safety lock to TEST MODE.
- b) Fill the fuel tank with qualified color fluid we prepared.
- c) To avoid color mix, it is highly recommended to fix the color used on each unit of cFlamer Waver. In case need to change to another color fluid please execute pipeline clean process (refer to 11. *Pump and pipeline cleaning* of this manual).

WARNING:

The warranty is void if any other type of color liquid or additive is used.

NOTICE:

SHOWVEN excludes liability for the losses, damages and accidents caused by not using qualified fuels in accordance with this requirement.

5. E-Stopper / E-stop terminator Connection

E-stop interface is a power cut-off interface, the machine can be powered on normally only when E-STOP in is connected. For safer use of CFlamer Waver we suggest to connect it with E-stopper. For operators who don't want to use E-stopper can plug a E-stop terminator in E-STOP IN to enable the device.

E-Stopper (optional) connect with single unit of cFlamer Waver.




E-Stopper (optional) connect with multi units of cFlamer Waver in daisy chain.



NOTICE: A unit of E-Stopper can control maximum 24 units of device.

Use E-stop terminator (standard configuration): if without E-Stopper. Plug the E-stop terminator to the E-STOP IN port to enable the cFlamer Waver.



6. Connecting cFlamer Waver

Make sure the DMX or pyro controller is disarmed or powered off during cable connection.

If control by DMX controller, follow below steps:

- a) Connect a DMX cable to the DMX IN socket of first unit of cFlamer Waver, another head of this DMX cable connect to DMX console (such as FXcommander). Make sure the DMX console is powered off.
- b) Connect a DMX cable to the DMX OUT socket of previous cFlamer Waver, and the other end to the DMX IN of next machine. Connect all devices in series in this way.
- c) Suggest to plug in a DMX terminator into the DMX OUT in last unit of machine to improve signal reliability. For distance >200m please use SHOWVEN DMX splitter 8 to amplify the signal.
- d) Connect a power cable to the POWER IN socket of cFlamer Waver. Make sure power supply in consistent with the rated voltage of the equipment, and the socket must well grounded.
- e) Power on all CFlamer Waver. Check the safety lock, double confirm it stays at "TEST MODE".



- f) Set the angle limit if needed
- g) Assign DMX address for each unit of cFlamer Waver. If use SHOWVEN host controller or FXcommander to control the machine please allocate a unique DMX address for each unit of machine.

If control by 9-60V pyro signal, follow below steps:

- a) Connect a power cable to the POWER IN socket of cFlamer Waver. Connect the other end of power cable to the power source. Make sure power supply is consistent with the rated voltage of the equipment, and the socket must well grounded.
- b) Connect the power control cables to the 9-60V pyro signal connector on cFlamer Waver.
- c) Connect the other end of power control cables to the pyro controller (9-60V external trigger source), such as SHOWVEN PyroSlave series module. Before connect please make sure there is no pyro signal input.
- d) Power on all cFlamer Waver
- e) Set the angle limit if needed
- f) Set the Ext Ignite to ON status in advanced interface, set the firing sequences at "Set Ext Sequence".

7. Power ON the DMX console / Pyro controller and programming


Power on DMX console and program the cFlamer Waver effect on DMX console or Pyro controller.

8. Test the ignition function of CFlamer Waver

Test the ignition function of cFlamer Waver, we can check whether the igniters of each unit of cFlamer Waver is working fine. Due to the safety switch is stay at TEST MODE there will be only ignition while jet solenoid valve is not open, so no flames generated.

9. Firing

- a) Double confirm the prescribed safety isolation zone is clear, no person, animal or other property within this region.
- b) Switch the safety lock of cFlamer Waver to USER MODE.



- c) Firing, the operator should always have a clear view of the device, so that he/she can stop the show immediately when there is danger.

NOTICE:

Due to the pump and pipeline cleaning procedure after each show, there will be some water remains in the pipeline, so the first several shots may spray water and fail ignition. Even though please make sure no person, animals or other flammable articles stays in the safety isolation area when firing.

10. Depressurize and Power OFF

- a) Depressurize the flame unit after show or not use flamer for a period of time
- b) Power OFF DMX console
- c) Press E-Stopper to power OFF all machine (if connect with E-stopper)
- d) Switch safety lock of cFlamer Waver to TEST MODE
- e) Power OFF each unit of machine

11. Pump and pipeline cleaning

- a) Suggest to conduct pump and pipeline cleaning process after each time use color fluid.

- b) There are three types of cleaning agent we suggest to use on cFlamer series based on different weather and availability.

Cleaning Agent	Environment temp.	Remark
H2O	> 0°C throughout the day	Make sure device always stay at environment with temp. above 0 degree, otherwise water freezing in pump will damage pump
30% methanol + 70% H2O	> -20 °C	Flamable cleaning agent, be aware of the safety isolation zone
99.5% methanol	No temp. restriction	Flamable cleaning agent, be aware of the safety isolation zone

- c) Collect all cFlamer, take the color fluid tank out and replace with water tank with no less than 2L cleaning agent inside.
 d) Connect with power and DMX cables, power on machine.
 e) Pressurize and depressurize cFlamer 3 times.
 f) Pressurize machine and firing 3 times with firing duration of 1s.
 g) Pressurize and depressurize cFlamer 3 times again.
 h) Empty the remaining cleaning agent in fuel tank

WARNING:

Pump and pipeline cleaning procedure is a mandatory operation after the machine is used, Not to do so will shorten the shelf life of cFlamer series product due to the corrosive of color fluid.

WARNING:

Before clean test, make sure there are sufficient purified water in the fuel tank. During the cleaning process, the flamethrower will spray a large amount of water, please ensure there is no non-waterproof objects or equipment around.

WARNING:

Forbidden to use water as cleaning agent when ambient temperature is below 0°C, otherwise water freezing in pump will damage pump. If use water as cleaning agent after previous usage but now the temperature is below 0°C, please put machine in environment with temp. >0°C for 4 hours before use.

NOTICE:



Pump and pipeline cleaning procedure is also a necessary operation when use a different color on cFlamer series product, Not to do so will cause abnormal flame color due to the remaining fluid from previous firing.

12. Clean and package machine

- a) Clean the water/liquid on machine, wait until it dry
 b) Package the machine after it is cool down

▲ Nozzle Replacement and Igniter Position Adjustment

1. Nozzle Types and Flame Height


Nozzle Type	Picture	Short Flamer Height (m)	Long Flame Height (m)
Nozzle cH SFSMA033		5-7m	8-10m
Nozzle cL SFSMA037		3-4m	5-6m

2. Nozzle Replacement

Use 14mm outer hexagon socket wrench (SFMET944) to disassemble the nozzle, clean the nozzle and nozzle socket with air gun (air compressor), change a new nozzle and install it.



3. Igniter Position Adjustment




Whenever changed the nozzle or ignition is not good, please check igniter pole position according to below parameters. The right position for each pair of pole should have a gap from tip to tip of 2.5-3mm (b) and a gap between two igniter of a 18 ± 1 mm (cH) and 13 ± 1 mm (cL). Check the ignition success rate after adjustment by firing.

WARNING: Do unplug the power cable and power off the machine when service flamer.

4. Nozzle Installation

Please assemble the stainless steel gasket, O ring and nozzle main part according to below picture. The O ring should be inside the stainless steel gasket, otherwise it may leads to fuel leakage.

Use nozzle replacement tool outer hexagon socket wrench to tighten the nozzle.



▲ Maintenance

1. To maintain the machine in good performance and running status, it is recommended to running the device at least once per month.
2. Check the ignition probes both before and after each show, if there is any foreign objects on it please clean it up.
3. Maintenance of the nozzle: Nozzle needs to be cleaned from time to time, and it is recommended that once every six months (depending on the environment and frequency of use). In the process of using the equipment, if the flame shape is seriously deformed or the fuel injection line is significantly deformed or coarsened, the nozzle should be removed immediately for cleaning. If after clean, there are still problems please replace new nozzle.
4. Maintenance of the O-ring: If it is found that the O-ring of the nozzle is damaged or ageing when cleaning the nozzle, the Fluorine rubber O-ring should be replaced in time. O ring outer diameter is 14mm, wire diameter is 2mm.
5. Please make the pump and pipeline cleaning procedure after each time use of color fluid.

▲ Optional Parts for CFlamer Waver

Part. No.	Description
SFSMA033	NOZZLE cH
SFSMA037	NOZZLE cL
RMSMA530	SS304 gasket, outer ϕ 18, inner ϕ 14, thickness 1.5mm
RMWAS112	Fluorine O ring, outer ϕ 14, wire diameter is 2 mm
SFMET1107	G1-E-Stop connector
FPEST001	E-STOPPER
FPFLI057	Flightcase for single unit
RMPCK379	Paper carton for flightcase
RMSMA637	FA2822 angle limit rod
RMPCK454	Safety loop
SFMET2416	FA06 fuel hose, 370mm length
RMBOT036	Safety Loop
SFMET944	Nozzle disassemble tool
RMEMD062	5-pin wireless DMX receiver (compatible with FXcommander 2.4GHz wireless DMX)
SFMET2032	Fuel tank lid assembly
RMINJ292	FA18 10L Fuel tank

▲ **Warranty Instructions**

- ∨ Sincere thanks for your choosing our products, you will receive quality service from us
- ∨ The product warranty period is one year. If there are any quality problems within 7 days after shipping out from our factory, we can exchange a brand new same model machine for you
- ∨ We will offer free of charge maintenance service for machines which with hardware malfunction (except for the instrument damage caused by human factors) in warranty period. Please don't repair machine without factory permission

Below situations NOT included in warranty service:

- ∨ Damage caused by use unqualified fuels;
- ∨ Damage caused by improper transportation, usage, management, and maintenance, or damage caused by human factors;
- ∨ Disassemble, modify or repair products without permission;
- ∨ Damage caused by external reasons (lightning strike, power supply etc.)
- ∨ Damage caused by improper installation or use;

For product damage not included in warranty range, we can provide paid service.

Invoice is necessary when applying for maintenance service from SHOWVEN

SHOWVEN[®]



Showven Technologies Co., Ltd.

Tel: +86-731-83833068

Web: www.showven.cn E-mail: info@showven.cn

Add: No.1 Tengda Road, Liuyang Economic & Technical Development Zone, Changsha, Hunan, 410300,
P.R.China