## FLAME SYSTEM ACCESSORIES:

## Hose



\ Main Hose 11/4 DN32



\ Branch Hose 3/8 DN10

- \ High pressure steel wire braided rubber hose.
- \ Main hose is used to connect between uPumper P20 to fuel dispenser, uPumper P20H to accumulator module or connection between T-shape fuel dispensers.
- \ Branch Hose with stainless steel quick coupler and Y shape filter, it is used to connect between fuel dispenser to flame head, accumulator module to uFlamer X20, uPumper P4 to flame head etc.

## **Accumulator module**





Accumulator module is designed to stabilize the system pressure of uPumper P20H and uFlamer® X20 flame system, ensure stable firing height of X20. And also it can storage pressure ensure longer firing durations.

## **Fuel Dispenser**



\T-shape dispenser T 11/4-11/4-11/4



\ Fuel dispenser 1 TO 6



\T-shape dispenser T 11/4-3/8-11/4



\Fuel dispenser 1 TO 12

\ Fuel distribution between pump station and flame heads. We have different size T-shape dispenser, 1to6 fuel dispenser, 1to12 fuel dispenser etc.